TABLE OF CONTENTS

Index

1	Before driving	1-4.	Opening and closing the windows and moon roof
			Power windows 75
1-1.	Key information		Moon roof 78
	Keys 24		
		1-5.	Refueling
1-2	Opening, closing and locking the doors and trunk		Opening the fuel tank cap
	Smart access system	1-6.	Theft deterrent system
	with push-button start 29		Immobilizer system84
	Wireless remote control 41		Alarm86
	Doors44		Theft prevention labels
	Trunk 49		(U.S.A.) 88
1-3	. Adjustable components	1-7.	Safety information
	(seats, mirrors, steering wheel)		Correct driving posture89
	Front seats54		SRS airbags 91
	Driving position memory system56		Front passenger occupant classification system 103
	Head restraints60		Child restraint systems 109
	Seat belts 64		Installing child restraints113
	Steering wheel71		
	Inside rear view mirror 72		
	Outside rear view mirrors 73		

2 W	hen driving		Using other driving systems Cruise control	
D Er A Tu Pa	Priving procedures Priving the vehicle		Dynamic radar cruise control	2
	nstrument cluster	2-5.	Driving information	3
In M 2-3. C	Deauges and meters		Cargo and luggage	4
Н	windshield wipers leadlight switch155			5
W,	og light switch			6
Н	leadlight cleaner switch 164			
				7

3 Interior features		3-4.	Using the hands-free system (for cellular phone)	
	Using the touch screen Touch screen		Hands-free system (for cellular phone) Using the Bluetooth® phone	315
	system and defogger Automatic air conditioning system	3-5.	Using the interior lights Interior lights list	356
	Rear window and outside rear view mirror defoggers 243 Windshield wiper de-icer 244	3-6.	Using the storage features List of storage features	359
3-3.	Using the audio system	3-7.	Other interior features Sun visors	366
	Audio system type		Vanity mirrors	367 368 370 370 373 373 375 376 378 378 382
	Using the steering switches 30/		Lexus Link System	392

4

4 Maintenance and care

4-1.	Maintenance and care
	Cleaning and protecting the vehicle exterior 406
	Cleaning and protecting the vehicle interior 409
4-2.	Maintenance
	Maintenance requirements 412
	General maintenance 414
	Emission inspection and maintenance (I/M) programs
4-3.	Do-it-yourself maintenance
	Do-it-yourself
	service precautions418
	Hood 421
	Positioning a floor jack 422
	Engine compartment 424
	Tires
	Tire inflation pressure448
	Wheels453
	Air conditioning filter455
	Electronic key battery 458
	Checking and replacing fuses460
	Headlight aim 485
	Light bulbs

5 When trouble arises

5-1.	Essential information	1
	Emergency flashers 496	'
	If your vehicle needs	
	to be towed 497	
	If you think something is wrong	2
	Fuel pump shut off system 504	
	Event data recorder 505	
		3
5-2.	Steps to take in an emergency	
	If a warning light turns on or	
	a warning buzzer sounds507	4
	If a warning message is displayed	
	If you have a flat tire (Vehicles with standard tires) 531	5
	If you have a flat tire (Vehicles with run-flat tires) 541	
	If the engine will not start 542	
	If the shift lever cannot be shifted from "P" 543	6
	If you lose your keys544	
	If the electronic key does not operate properly545	7
	If the 12 volt battery is discharged 548	
	If your vehicle overheats 552	
	If the vehicle becomes stuck	

TABLE OF CONTENTS Index

6	Vehicle specifications	7 For US owners	
6-1.	Specifications Maintenance data (fuel, oil level, etc.)	Reporting safety defects for U.S. owners	
6-2.	Customization	Index	
6-3.	Customizable features	Abbreviation list	
		What to do if 6	14

